

# INSTALLATION INSTRUCTIONS



1. Using a spade or shovel create a "V" in the ground along the intended line 4-5in deep.



2. Install the edging by aligning the Greenline® Depth Indicator with the ground leaving approximately 3/4in above the ground. This will create an effective root barrier while reducing interference with lawn equipment.



3. Secure edging using metal stakes placed every 3-4ft.



4. Connect 20ft lengths by overlapping 6in and secure with two metal stakes.